

AeroSkull

USER GUIDE

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Preface by MusicLife Ltd.

Jarre Technologies, founded by the musical legend, Jean Michel Jarre has unveiled its latest speaker system, the Aeroskull. Uniquely designed to arouse fascination and curiosity, the Aeroskull is a monument to design, power and precision.

Optimal sound quality goes hand in hand with design at Jarre Technologies. The Aeroskull features two 15 Watt speakers hidden behind sunglasses with an impressive 40 Watt Sub Woofer covering the whole of the back of the skull as well as 1% THD (Total Harmonic Distortion), to deliver an uncompromising listening experience.

Jean Michel Jarre first used the image of the skull in 1976 on the cover of his world renowned album, Oxygene which sold over 15 million copies. He says, "For me, the skull symbolises the perfect acoustic instrument it is the sound box for word, song and music."

The Aeroskull is compatible with all generations of iPhones and iPods and a jack cable can also connect to any Mp3 player, computer or CD/DVD player. Bluetooth simplifies connection to any smartphone and the listening experience is optimised by the APTX codecs.

MUSICLIFE^{LTD}

-
-
-
-
- PREFACE BY MUSICLIFE LTD.**
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS

Preface by Jean-Michel Jarre

Today we listen to more music than at any time in our history.

We're listening everywhere and anywhere, while paying less attention to how we do so. Whether experiencing audio through the miniature plastic speakers of a laptop, the cheap earphones connected to our mobile phones, or the small sound-systems in public areas, we have gradually abandoned our demand for quality, and in the process, I believe, our emotional relationship with sound.


For many years I dreamt of a sound system that would evoke one of the iconic designs associated with our musical heritage, such as the elegant phonograph or the glossy jukebox, while complementing virtually any interior. At the heart of this design would be a sound system powerful enough to do justice to every kind of music (including mine!) at any volume, combining a strong, clear bass with superb definition in the higher frequencies. The sound system of my dreams is now a reality.

The world-class yet affordable AeroSkull® will gratify lovers of both music and design, while rendering every kind of music in a multitude of platforms and formats, including iTunes .mp3s and superior-quality .wav files. Here at last is the performance I've longed for in the form I've desired.

I hope the AeroSkull® gives you as much listening pleasure in your home as it gives me in mine.

Bonne écoute!







Jean-Michel Jarre



-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE**
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

In the box

- ① One AeroSkull
- ② One remote control
- ③ One Quick User guide
- ④ One Power supply
- ⑤ One S size Adaptor iPhone® / iPod® adaptors
- ⑥ One M size Adaptor iPhone® / iPod® adaptors
- ⑦ One L size Adaptor iPhone® / iPod® adaptors
- ⑧ Two AAA batteries for the remote control
- ⑨ One dock cap




-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- **IN THE BOX**
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Product Description of the AeroSkull®


Total output power 70 W RMS at 1% THD+N
2.1 System with built-in subwoofer
Bass Reflex Cabinet
Bluetooth®, A2DP, atpX® for high quality wireless audio
Line-in 3.5mm
30 pin connector
Touch sensor control
IR remote with backlight
Meets all Apple requirements for Made for iPod and iPhone docking speaker.

-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®**
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-


Using the Dock



To start, plug the AeroSkull® into the power socket and press the power button located at the back of the speaker.



Dock your iPhone® or iPod® on top of the AeroSkull® to start playing music. Please see Appendix 1 for a detailed compatibility list.



Turn on your favourite music and enjoy the sound!

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- **AEROSKULL® QUICK START**
 - **Using the Dock (only for Apple® products)**
 - Using Bluetooth
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS

Using Bluetooth

Connecting to Iphone® or Ipod®:

- Make sure no device is docked on the AeroSkull®;
- Go to Settings on your iOS device;
- Look for General in the list;
- Then under General go to Bluetooth;
- Make sure Bluetooth is On;
- Under Devices tap the list item AeroSkull to connect;
- Once connected the Bluetooth Led light will turn on.

Connecting to Android® Phones:


- Make sure no device is docked on the AeroSkull®;
- Go to Settings;
- Tap on Bluetooth;
- Turn On the Bluetooth;
- Look for AeroSkull in the list of Available Devices;
- Tap on the list item AeroSkull to pair and connect;
- Once connected the Bluetooth Led light will turn on.

Connecting to Windows® Phones:

- Make sure no device is docked on the AeroSkull®;
- Once connected the Bluetooth Led light will turn on.


Connecting to Apple® Laptop or Desktop:

- Make sure no device is docked on the AeroSkull®;
- Turn on Bluetooth on your computer;
- On Decktop top navigation bar click on the Bluetooth icon and from the Bluetooth dropdown select Set Up Bluetooth Device;
- From the list of devices select AeroSkull and press Continue, wait for the confirmation message;
- Go back to the Bluetooth dropdown on the navigation bar;
- Roll over the AeroSkull on the list, another dropdown will appear;
- Select Use as Audio Device;
- Now you can play the audio of your computer directly from the speaker;
- Once connected the Bluetooth Led light will turn on.



-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- **AEROSKULL® QUICK START**
 - Using the Dock (only for Apple® products)
 - **Using Bluetooth**
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS

Aeroskull® remote control



Subwoofer Boost button

Menu button

Go to next song

Go to previous song

Play/Pause button. Hold for more than one second to toggle to stop mode

Volume Up button

Volume Down button

Mute button (0dB)

Switch to Line-in, USB, iPod® or iPhone®, Bluetooth

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- **AEROSKULL® REMOTE CONTROLL**
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Operating the AeroSkull®

Volume Control:

The two frontal teeth of the AeroSkull® can be used to control the volume. The Volume can be increased or decreased by simply touching either + or -.

White LED light indicator:

This LED light located on the front middle top of the AeroSkull Sun Glasses, it is a white light that blinks whenever using the IR (Infra Red) remote control of the AeroSkull®. This light is steady white when on Line-in mode.

Blue LED light indicator:

It is located on the right tooth and supports only one color

- Steady blue when on Bluetooth mode
- LED light indicator is OFF when iPod® - iPhone® Device is docked or when line-in mode is active.
- LED light blinks every time teeth touch control is activated.

iPod® - iPhone® Docked mode:


This mode is active when an iPhone® or iPod® is docked on the 30pin connector located on top of the AeroSkull®

Bluetooth mode:

To enable Bluetooth turn On Bluetooth on your device and go to the list of available devices. Look for AeroSkull between the list of the available devices then select AeroSkull to connect to the speaker. If AeroSkull does not appear on the list, please turn your speaker Off and then back On. Once you have successfully connected to the AeroSkull, you will now be able to stream audio if the Tooth LED Light Indicator of the AeroSkull will show a steady blue color. If not you can switch to the Bluetooth mode by pressing AUX button (last button from top to down) on the remote control.

Line-in mode:

To enable line-in mode you can connect a 3.5mm jack to the AeroSkull® and play audio directly from your favourite device. Line-in port is located at the back of the AeroSkull® next to the Power On/Off button.



- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- **OPERATING THE AEROSKULL®**
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS

Operating the Remote Control

Navigating through the iPhone and iPod

Pressing <MENU> will take you to your iPhone or iPod's menu. As soon as you press <MENU>, the remote will enter Navigation mode. Navigation mode will automatically exit after 15 seconds. To exit quickly, press the <BASS> button. In Navigation mode, the < > and < > buttons are used to navigate up and down in the menu and the < > button is used as the <Enter> button.

Navigate to the Line in Mode

Use the <AUX> button to switch to Line-in mode.

Navigating to Bluetooth Mode

Use the <AUX> button to switch to Bluetooth Mode.

Muting the speaker

To completely exclude the audio from the AeroSkull Press the Mute button on the remote control. Note that the audio file on your device will keep playing when the AeroSkull is on Mute.

Bass Boost


This feature will activate the bass boost.

Navigate through the docked device

You can use the main button on the remote control to activate the navigation mode on the docked device. When activating the navigation mode on your device the remote will be acting as a joystick. + will be UP and - will be Down then MENU button will be BACK and < > button will be NEXT/SELECT.

The AeroSkull will leave navigation mode after you select a new song or when a new song will start playing.

To leave the Navigation mode without effecting the current song you can press the AUX button. Note this will switch to a differe



-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Maintenance and Care

Maintenance may include periodically cleaning the AeroSkull® and replacing the remote control battery.

Cleaning

Turn off the AeroSkull® and unplug it before cleaning. To clean the exterior, use a soft, dry cloth such as the one provided.

DO NOT USE SOLVENTS OR SPRAYS.

DO NOT ALLOW LIQUIDS TO SPILL OR OBJECTS TO DROP INTO ANY AEROSKULL® OPENING.

Replacing the remote control batteries

When the remote control stops operating or its range seems diminished, it's time to change the batteries:

- Open the battery cover placed at the back of the remote control;
- Replace the batteries with the same mode number of batteries (AAA);
- Close the battery cover.

Batteries precautions

- The batteries must be replaced by an adult.
- The batteries must not be short circuit.
- The used batteries must be replaced.



CAUTION : There is a danger of explosion if battery is incorrectly replaced. The new battery must be the same model as the old one. Do not put the battery into fire as it may explode or leak. Dispose the battery properly.

Place the AeroSkull® on a flat and stable surface. It should not stand in direct sunlight or near water sources, humidity sources, heat, dust, vibrations or high magnetic fields. To ensure the best sound quality from your AeroSkull®, we strongly recommend a compression rate of 256kb or higher for all mp3 or wma files.

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROL
- **MAINTAINANCE AND CARE**
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

First Help before assistance

Problem	Possible Cause of the problem	Possible solutions
Do not hear any sound from the AeroSkull®.	No Power Supply	Make sure that the electric plug is connected to AC Socket and the switch is in < On > position.
	The volume level is too low	Check that the mute function is Off. Increase volume.
	Your iPod or iPhone product does not have songs in memory or it does not work	Check other input USB or Line-in; if OK, check with another Apple product.
	The Apple product is in < stop > mode or < pause > mode	Check on the Apple product screen that the song track is playing.
The product does not switch on.	The plug is not fully inserted in the socket	Check that the plug is correctly inserted into the socket. Try to plug and unplug your AeroSkull®.
The remote control is not working.	The battery is out of power.	Replace the battery.
	Sensor not in accessible range by the remote.	Check that no obstacle is between the remote and the infrared sensor.
The iPod is not responding or not charging.	The battery has been installed in the wrong position.	Open the remote battery cover and check that the (+) side is on the top.
	The iPod is not fully inserted on the connector.	Unplug the iPod and plug it in again.
	The adapter does not matching the Apple product model.	Check the instruction manual and make sure that the adapter matches the Apple product you are using.
If you have any questions regarding the compatibility of your iPod/iPhone product with the AeroSkull®, visit support.jarre.com for the most updated information.		

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- **FIRST HELP BEFORE ASSISTANCE**
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Safety Information



Important information related to the safety of the product.

To prevent electrical shocks never try to open the product.

In order to prevent fire and electrical shock, do not use the power cord with extension, socket of any other accessories except if the plug can be completely inserted and the electrical pin are not accessible. In order to prevent any risk of fire or electric shock, do not expose the product to rain or humidity.

Power Supply

This product is designed to work with a power supply of 230V-50Hz. Connecting this product with a different source of power can damage the product.

Important Notices

- 1 - Read, follow and keep the instruction manual for reference.
- 2 - Do not use this product near water.
- 3 - Clean the product only with a soft and dry fabric. Never use liquid cleaning product as it will damage the product.
- 4 - Avoid placing the product in a location under the sunlight or near any appliance that generates heat such as an electric heater or above other Hi-Fi product that will generate heat. Avoid locations that lack ventilation are dusty, humid or exposed to vibration.
- 5 - If you are not able to insert properly the plug into the socket located on the wall, you have to contact an electrician.
- 6 - Ensure that the power cord is out of the way and will not be stepped on.
- 7 - Before you power on the product, make sure that the power cord is properly installed.
- 8 - Use only spare parts and accessories specified by the product manufacturer.
- 9 - Unplug the product during storms or when the product won't be used for a long period of time. 10 - Contact a qualified worker for maintenance on the product. Maintenance will be needed if the product has any damage.
- 11 - To reduce the risk of fire or electrical shock, this product should not be exposed to drop of water spray. Never try to open the product by yourself.
- 12 - When you have to relocate the product, make sure you turn off the switch and then unplug the power cable..
- 13 - Handle the product carefully when you are moving it in order to prevent injuries if the product flip.
- 14 - Use the control switch and button as per stated in the instruction manual.

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- **SAFETY INSTRUCTIONS**
 - **Safety information**
 - Environment information
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-

Environment information

Important information related to environment



This product had been designed in conformity with international standards that limit the use of dangerous substances (RoHS) in electrical appliances and the possibility to recycle some material (WEEE). You need to get information relative the way to discharge the product.



This symbol is printed on batteries or packaging; it means that the batteries delivered with your product should not be proceed like other domestic waste. This product is designed for indoor use only.



This product is designed for indoor use only.

Author copyright

The music data transferred/recorded cannot be used without the approval of the owner of the right except for personal use.

-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS**
 - Safety information
 - Environment information**
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-

Appendix I – Compatible Devices

iPhone®



iPhone
4GB 8GB 16GB



iPhone 3G
8GB 16GB



iPhone 3GS
8GB 16GB 32GB



iPhone 4
8GB 16GB 32GB



iPhone 4S
16GB 32GB 64GB

iPod nano®



iPod nano
1st generation
1GB 2GB 4GB



iPod nano
2nd generation
(aluminum)
2GB 4GB 8GB



iPod nano
3rd generation
(video)
4GB 8GB



iPod nano
4th generation (video)
8GB 16GB




iPod nano
5th generation (video camera)
8GB 16GB




iPod nano
6th generation
8GB 16GB


iPod touch®



iPod touch
1st generation
8GB 16GB 32GB



iPod touch
2nd generation
8GB 16GB 32GB



iPod touch
3rd generation
32GB 64GB



iPod touch
4th generation
8GB 32GB 64GB

iPod classic®



iPod classic
80GB



iPod classic
160GB (2007)



iPod classic
160GB (2009)

-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- **APPENDIX I – COMPATIBLE DEVICES**
- APPENDIX II – AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Appendix II – AeroSkull® guarantee

AeroSkull® ships with two years warranty.

-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I – COMPATIBLE DEVICES
- APPENDIX II – AEROSKULL® GUARANTEE**
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Appendix III – Product FAQ

The following section presents questions and answers about the functionality of the product.

Q. Will the product be able to do stream wav and flac files?

A. Yes. If your device supports aptX®.

Q. The volume control seems not to work correctly sometimes. What is the reason?

A. There are few known reason for which the touch control may not work correctly.
1. Could be the moisture of the fingers.
2. The pressing motion.

Q. The remote control is not longer working. What can I do?

A. Before contacting support please make sure you have completed the following steps:
1. Replace batteries in the remote control.
2. The AeroSkull is ON when trying to operate the remote.
3. Make sure you are not in Navigation mode. Press the AUX button to force exit from navigation mode.

If you have tried all of the above and the remote is still not responding please contact your reseller or support at support.jarre.com

-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I - COMPATIBLE DEVICES
- APPENDIX II - AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ**
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS
-
-
-

Appendix IV – Trademarks & Certifications



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Music Life LTD is under license. Other trademarks and trade names are those of their respective owners.



aptX® software is copyright CSR plc or its group companies. All rights reserved. The aptX® mark and the aptX logo are trademarks of CSR plc or one of its group companies and may be registered in one or more jurisdictions



-
-
-
-
-
- PREFACE BY MUSICLIFE LTD.
- PREFACE BY JEAN-MICHEL JARRE
- IN THE BOX
- PRODUCT DESCRIPTION OF THE AEROSKULL®
- AEROSKULL® QUICK START
- AEROSKULL® REMOTE CONTROLL
- OPERATING THE AEROSKULL®
- OPERATING THE REMOTE CONTROLL
- MAINTAINANCE AND CARE
- FIRST HELP BEFORE ASSISTANCE
- SAFETY INSTRUCTIONS
- APPENDIX I - COMPATIBLE DEVICES
- APPENDIX II - AEROSKULL® GUARANTEE
- APPENDIX III - PRODUCT FAQ
- APPENDIX IV - TRADEMARKS & CERTIFICATIONS**
-
-
-